GS83.E MACHINE MANUAL

PARTS INTRODUCTIONS

RF AND CAVITATION HEADS

ULTRASOUND HEAD

MEDIUM SUPERSONIC HEAD

SMALL SUPERSONIC HEAD

BASIC OPERATIONS:

1. PLACE THE MACHINE ON A FLAT LEVELED SURFACE. DO NOT LEAN IT ON THE WALL. ALLOW AT LEAST APPROXIMATELY 30 CENTIMETERS OR 1 FOOT SPACE FROM THE WALL TO ALLOW THE FAN AND FILTER TO OPERATE AND AVOID OVERHEATING



2. CONNECT THE ULTRASOUND HEAD, MEDIUM SUPERSONIC HEAD AND THE SMALL SUPERSONIC HEAD TO THE MACHINE

3. PLUG IN THE POWER SUPPLY CORD TO THE MACHINE THEN TO THE POWER SOURCE.

4. TURN ON THE GENERAL POWER SWITCH (RED SWITCH). THE RED LIGHT WILL TURNED-ON.

5. SET THE MACHINE. PRESS THE ***SELECT*** BUTTON. SET THE TIME (MINUTES) OF THE OPERATIONS EXAMPLE: 5 MINUTES, 15 MINUTES OR 20 MINUTES.

6. PRESS THE ***SELECT*** BUTTON, SET THE WAVES (PULSE WAVE OR CONTINUOUS WAVE).

7. PRESS THE ***SELECT*** BUTTON, SET THE INTENSITY 1, 2, 3, 4, 5.

8. PRESS THE ***SELECT*** BUTTON, SET THE FUNCTION HEAD, ***1*** FOR THE ULTRASOUND HEAD, ***2*** MEDIUM SUPERSONIC HEAD OR ***3*** SMALL SUPERSONIC HEAD.

9. APPLY ULTRASONIC GEL OR OIL ON THE BODY SURFACE.

10. PRESS **START** BUTTON

11. DURING THE OPERATIONS. PRESS ***PAUSE*** FOR AWHILE, DO NOT MAKE CONTINUOUS OPERATIONS TO AVOID OVERHEATING/MALFUNCTION. PRESS ***PAUSE*** WHEN THE HEADS ARE NOT IN USE.

12. DO ***NOT*** PRESS THE HEADS ON SINGLE AREA FOR VERY LONG TIME

13. DO ***NOT*** RUB THE HEADS ON BONED AREAS OF THE BODY.

14. DO ***NOT*** RUB THE HEADS ON THE ADAM'S APPLE ON THE NECK

15. AFTER USING THE MACHINE, ***TURN OFF*** THE MAIN POWER. ***REMOVE*** ALL THE CONNECTIONS OF THE HEADS . SANITIZED THE HEADS BY WIPING THE SURFACE WITH MILD CLEANING AGENTS SOFT CLOTH OR ***WARM TOWELS***. WIPE IT CLEAN AND STORE THEM PROPERLY

16. DO ***NOT*** USE ALCOHOL IN CLEANING ANY PARTS OF THE MACHINE

ULTRASONIC FUNCTIONS

1. ***APPLY ULTRASONIC GEL***/ OIL ON THE BODY SURFACE LIKE ABDOMEN, HIP OR THIGH. THIS WILL HELP THE HEADS SLIDE SMOOTHLY ON THE AREAS MENTIONED.

2. **SET** WORK TIME 5 TO 10 MINUTES EVERY AREA

3. ADJUST ***OUTPUT INTENSITY*** 1 WEAK UP TO 5 STRONG

4. THE BEAUTICIAN HOLD THE ULTRASOUND HEAD ON ONE HAND AND MOVE IT SLOWLY ON THE BODY SURFACE, IN CIRCULAR MOTION OR BEELINE REPEATEDLY, WHILE THE OTHER HAND PUSH THE FAT TOWARDS THE ULTRASOUND HEAD

5. DO ***NOT*** USE ON THE BACK PORTION OF THE BODY, TO AVOID THE BONES. DO NOT USE ON THE RIB PORTION OF THE BODY.

6. DO ***NOT*** USE ON THE UTERUS AREA, WHEN THE CLIENT HAS A MENSTRUAL PERIOD

7. APPLY GEL ***GENEROUSLY*** ON THE AREA TO AVOID PAIN AND STICKY MOVEMENT OF THE HEAD

8. THE MACHINE WILL ***PAUSE AUTOMATICALLY*** WHEN THE SET TIME IS OVER

SUPERSONIC FUNCTION

SUPERSONIC HAS A MECHANICAL, HYPERTHERMIA AND BIOCHEMICAL EFFECTS. IT SENDS MICRO-MASSAGE TO TISSUE CELLS. IT PROMOTES BETTER BLOOD CIRCULATION AND SPEED UP CHEMICAL REACTIONS AND PROMOTES BETTER METABOLISM. IT HELPS IN LYMPH CIRCULATION AND HELPS IN BODY DETOXIFICATIONS. HELPS REMOVE WRINKLES BY TIGHTENING THE SKIN, LIFTING, AND ELIMINATING FATS AND SAGGING OF SKIN.

1. CLEAN THE HEAD OF THE MEDIUM SUPERSONIC HEAD. APPLY ULTRASONIC GEL ON THE BODY SURFACE (FACE)

2. SET WORK TIME (5 MINUTES OR 10 MINUTES)

3. SET WORK MODE USING UP AND DOWN BUTTONS, SET WORK MODE CONTINOUS WAVE OR PULSE WAVE

4. PRESS THE FUNCTION AT 2 OR 3 (MEDIUM OR SMALL SUPERSONIC HEAD)

5. PRESS START

6. DURING OPERATIONS, IF YOU WANT TO CHANGE SETTING PRESS PAUSE AND SET THE MACHINE AGAIN THEN PRESS START AFTER ADJUSTING TO THE DESIRED SETTINGS. YOU CAN ADJUST THE WORK TIME, THE WAVES OR OUTPUT INTENSITY

7. THE MACHINE WILL AUTOMATICALLY PAUSE WHEN THE TIME SET IS OVER

8. AFTER USING THE MACHINE. TURN OFF AND DISCONNECT ALL CABLES. USE WARM WATER TO CLEAN THE BODY AFTER THE OPERATIONS

9. USE WARM WATER/ OR WITH MILD CLEANING AGENT ON CLEANING THE MACHINE PARTS. NEVER USE ALCOHOL IN ANY MACHINE PARTS

GUIDE ON INTENSITY AND WORKTIME ON SUPERSONIC HEADS

APLICABLE AREAS	SUPERSONIC HEADS	OUTPUT INTENSITY	WORK MODE	WORK TIME
Tighten, lift or outline shaping	MEDIUM	6-9	CONTINOUS WAVE OR PULSE WAVE	30 MINUTES WITH PAUSES IN BETWEEN
Wrinkle Removal, whitening, lightening	MEDIUM	5-9	CONTINOUS WAVE OR PULSE WAVE	20 MINUTES WITH PAUSES IN BETWEEN
Eye areas, dispel dark circles , fat pouches	MEDIUM OR SMALL	3-7	CONTINOUS WAVE	20 MINUTES WITH PAUSES IN BETWEEN
Sensitive skin	MEDIUM	3-5	PULSE WAVE	10 MINUTES

REMINDERS:

1. USE GEL/OIL ON BODY SURFACE GENEROUSLY
2. PRESS PAUSE IN BETWEEN OPERATIONS. DO NOT USE THE MACHINE CONTINOUSLY OVER A LONG PERIOD OF TIME TO AVOID DAMAGE OR OVERHEATING
3. DO NOT STAY THE ULTRASOUND HEADS ON ONE AREA OVER A LONG PERIOD OF TIME
4. NEVER USE THE HEADS ON BONED AREAS
5. NEVER USE THE HEADS ON TOP THE EYE BALLS AREAS
6. NEVER USE IT ON THE ADAM'S APPLE AREA

CONTRAINDICATIONS

DANGER – IF USED INCORRECTLY, WILL BRING DEATH OR SERIOUS INJURY TO THE CLIENT

1. DO NOT USE ON PATIENTS WITH HEART REGULATOR IMPLANTS , PACEMAKERS OR OTHER ELECTRO-CADIOVASCULAR SCANNER
2. DO NOT USE ON PATIENTS WITH ARTIFICIAL/METAL BONES IMPLANTS
3. DO NOT USE ON PATIENTS WITH SILICOSIS
4. DO NOT USE ON DRUNK PATIENTS
5. DO NOT USE ON PATIENTS WITH HIGH FEVER
6. DO NOT USE ON MENTAL PATIENTS
7. DO NOT USE ON UNCONSCIOUS PATIENTS
8. DO NOT USE ON EPILEPTIC PATIENTS
9. DO NOT USE ON PREGNANT PATIENTS
10. DO NOT USE ON PATIENTS WITH SEVERE HYPERTENSION, SEVERE CARDIOVASCULAR DISEASES, SEVERE CEREBRO-CARDIOVASCULAR
11. DO NOT USE ON PATIENTS WITH MALIGNANT TUMORS
12. DO NOT USE ON PATIENTS WITH RENAL FAILURE
13. DO NOT USE ON PATIENTS WITH SEVERE INFECTIONS

WARNING – WITH POSSIBILITY OF DEATH OR SERIOUS INJURIES

1. DO NOT USE ON WOMEN DURING THEIR MENSTRUATION
2. DO NOT USE ON CHILDREN
3. DO NOT USE ON PATIENTS WITH HEMMORRHAGIC DISEASES, TRAUMA, SKIN DISEASES, SKIN INFECTIONS
4. DO NOT USE ON PATIENTS WHO ARE NUMB AND WHO LACKS FEELINGS ON HEAT OR COLD.
5. DO NOT USE ON PATIENTS WITH IMMUNE SYSTEMS DEFECTS

6. DO NOT USE ON PEOPLE WHO JUST HAD FACE LIFTING
7. DO NOT USE ON PEOPLE WHO HAS ARTIFICIAL IMPLANTS

ATTENTION

1. ALWAYS CHECK ON THE HOSTS, CABLES, ACCESSORIES, POWER SUPPLY IF BROKEN BEFORE USING THE MACHINE
2. DO NOT USE THE MACHINE WITH INTERFERANCE WITH OTHER MACHINES.
3. BEFORE USING THE MACHINE, REMOVE ALL OTHER ACCESSORIES OF THE PATIENT, REMOVE HEARING AID, WRISTWATCH, MAGNETIC CARDS, MOBILE PHONES.
4. KEEP THE MACHINE OUT OF CHILDREN'S REACH
5. DRINK WATER BEFORE AND EVEN DURING THE OPERATIONS
6. IMMEDIATELY TURN OFF THE MACHINE IF THIS SITUATION HAPPENED:
    a. WATHER AND OTHER MATERIALS ACCIDENTALLY SPILLED ON THE MACHINE
    b. ABNORMAL HEATING OF THE MACHINE
    c. UNUSUAL SOUND OF THE MACHINE
    d. ACCESSORIES HAVE BEEN DAMAGED
    e. NATURAL DISASTER LIKE EARTHQUAKE OR TYPHOON
7. AFTER USING THE MACHINE, DISCONNECT ALL THE CABLES AND POWER SUPPLY
8. STORE THE MACHINE ON VENTILATED ROOM
9. DO NOT USE THE MACHINE ON SEVERE HOT AND HUMID ENVIRONMENT
10. DO NOT USE THE MACHINE ON DUSTY ENVIRONMENT
11. DO NOT USE THE MACHINE ON SMOKED OR STEAMED ENVIRONMENT

MAINTENANCE

1. KEEP THE MACHINE CLEAN AND FREE FROM DUST
2. SANITIZED THE HEADS WITH WARM WATER AND DRY THEM BEFORE STORING THEM.

WARRANTY *– Warranty is for the period of SIX (6) MONTHS. THIS WARRANTY IS THE SOLE AND EXCLUSIVE REMEDY FOR ANY DEFECTS OF THE MACHINE ARISING FROM ITS MANUFACTURING.*

SHIPPING CHARGES *- You are required to pay for packaging and shipping of the Device to our office. However if upon receipt, inspection and testing of the Device and was determined that the Device does not exhibit material defects in materials or workmanship, you will be required to pay for return packaging and the machine will be shipped back to you. In case, that the machine required further repairs, we will purchase the parts from our suppliers abroad. It is expected that the machine will remain with us for 14 days for us to purchase the items. After the machine has been repaired. We will ship the machine back to you.*

LIMITATION OF WARRANTY. *This warranty does not cover damage resulting from accident, misuse (including use not described in the user manual or instructions accompanying the Device), abuse, lack of reasonable care, the affixing of any attachment not provided with the device, loss of parts, use of unauthorized replacement parts or subjecting the device to anything other than the specified voltage.. This warranty is void if the Device is repaired by anyone other than us. We will not have any liability for damage resulting from service performed by others.*